

NOLANOSAL

SNOISIAB

8100

	puidop,							
AUM	1 - Separate 120V Wiring Package (Requir With VFD) - Three Phase Only	pəsn pue pə	only for DCV o	r Prewire				
	1 - Evaporative Cooler Winng Harness							
	1 - I 12-BDD Damper							
usia	1 - SCR-12 Bird Screen							
	1 - ECM Wiring Package-Exhaust - Manua	or 0-10VDC	Reference Spe	ed Control	(NIDEC			
V7-17	1 - Fan Base Ceramic Seal - Installed At P	ant - For Gre	ase Ducts					
EE-EX	- Grease Box							
ÐAT		D	49) NOIT9	Descr.)				
OILIO	,SN							
AUM	01D-1A	019	ĮΑ	2252	0.400	66 0	S	0.1
ÐAT	# HODEL #	EVAN NNIL WODER * BROMEK HONZING CEW				ая	W	·н
NVI	DYE#dol — Voitamaoyv	2097						
ЧајО	AHSIUD	009	004.0	299T	0.250	0591.0	ĩ	r -
X3-13	A3H081UD	3262	1,300	1335	2.000	1,2060	3	2
ิจ∀เ	# Jadom Tinu NAa	CEW	-dSE	КРМ	Ч.Р.	.9.H.8	ø	N.
	Aid Adm Aum Aum Aum Aum Aar Aar Aar Aum	FF-EX     DUI80HEA       AHNE IUD     AHSUD       And DUISUHEA     DUISUHEA       A     DORANDA       A     DORANDA       A     AND       A <t< td=""><td>FE-EX         DU180HFA         3262           Dish         DU120HFA         3262           FE-EX         L - Expandence         600           TAG         FAN UNIT MODEL #         BLOWER           PISh         1 - 112-60D Bamper         0-100454/04607           TAG         FAN UNIT MODEL #         BLOWER           PISh         1 - 12-60D Bamper         G10           MUA         AL-GRAGE-Exhaust - Manal or 0-10VDCI         0           DOPTIONS         O         0         0           MUA         AL-GRAGE Carant Scal - Installed At Plant - For Grage Motion)         0         0           MUA         AL-GRAGE Carant Scal - Installed At Plant - For Grage Motion)         0         0           PISh         I - ECM Wing Package-Exhaust - Manual or 0-10VDCI         0         0           MUA         AL-GRAGE Carant Scal - Installed At Plant - For Grage Motion)         0         0           MUA         AL-GRAGE Carant Scale Carant Scale I - Installed At Plant - For Grage Motion)         0         0           MUA         I - ECM Wing Package-Exhaust - Manual or 0-10VDCI         0         0           MUA         I - ECM Wing Package-Exhaust - Manual or 0-10VDCI         0         0</td><td>EF-EX         DUI30HFA         3262         1.300           Dish         DU12HFA         600         0.400           FMM         INFORMATION         Job4\$</td><td>Pipe         Dish         <thdish< th="">         Dish         Dish         <thd< td=""><td>EF-EX         DU130HFA         3262         1.300         1332         2.000           Pish         DU12HFA         600         0.400         I.657         0.350           FMA         INFORMATION         J.00490         I.657         0.350         0.350           FMA         INFORMATION         J.00493         Anula         0.400         I.657         0.350           FMA         INFORMATION         J.00483         PLOUSING         DEJICH         D.400         I.67         E59.           MUA         Anuent model         Anuent on 0.100VC Reference Speed Control (NIDEC         I.112-BDD Damper         0.400         I.67         0.400         I.67         E59.           Dish         I.112-BDD Damper         O         O.100VC Reference Speed Control (NIDEC         I.112-BDD Damper         I.112-BDD Damper</td><td>FE-EX         DU180HFA         3262         1.300         1332         2.000         1.000           I - EXPARE         Comparison         CPM         MIDE         CPM         MIDE         CPM         MIDE           I - EXPARE         Comparison         CPM         CPM<td>MUA         Mith VED) - Three Phase Only         MIDE         CCM With Phanes           TAG         Fe-EX         C112-EDD Damper         0.400         1657         0.400         1678         1           MUA         I - Separate IZOV Wining Phaces         0.400         1679         0.400         1687         1         &lt;</td></td></thd<></thdish<></td></t<>	FE-EX         DU180HFA         3262           Dish         DU120HFA         3262           FE-EX         L - Expandence         600           TAG         FAN UNIT MODEL #         BLOWER           PISh         1 - 112-60D Bamper         0-100454/04607           TAG         FAN UNIT MODEL #         BLOWER           PISh         1 - 12-60D Bamper         G10           MUA         AL-GRAGE-Exhaust - Manal or 0-10VDCI         0           DOPTIONS         O         0         0           MUA         AL-GRAGE Carant Scal - Installed At Plant - For Grage Motion)         0         0           MUA         AL-GRAGE Carant Scal - Installed At Plant - For Grage Motion)         0         0           PISh         I - ECM Wing Package-Exhaust - Manual or 0-10VDCI         0         0           MUA         AL-GRAGE Carant Scal - Installed At Plant - For Grage Motion)         0         0           MUA         AL-GRAGE Carant Scale Carant Scale I - Installed At Plant - For Grage Motion)         0         0           MUA         I - ECM Wing Package-Exhaust - Manual or 0-10VDCI         0         0           MUA         I - ECM Wing Package-Exhaust - Manual or 0-10VDCI         0         0	EF-EX         DUI30HFA         3262         1.300           Dish         DU12HFA         600         0.400           FMM         INFORMATION         Job4\$	Pipe         Dish         Dish <thdish< th="">         Dish         Dish         <thd< td=""><td>EF-EX         DU130HFA         3262         1.300         1332         2.000           Pish         DU12HFA         600         0.400         I.657         0.350           FMA         INFORMATION         J.00490         I.657         0.350         0.350           FMA         INFORMATION         J.00493         Anula         0.400         I.657         0.350           FMA         INFORMATION         J.00483         PLOUSING         DEJICH         D.400         I.67         E59.           MUA         Anuent model         Anuent on 0.100VC Reference Speed Control (NIDEC         I.112-BDD Damper         0.400         I.67         0.400         I.67         E59.           Dish         I.112-BDD Damper         O         O.100VC Reference Speed Control (NIDEC         I.112-BDD Damper         I.112-BDD Damper</td><td>FE-EX         DU180HFA         3262         1.300         1332         2.000         1.000           I - EXPARE         Comparison         CPM         MIDE         CPM         MIDE         CPM         MIDE           I - EXPARE         Comparison         CPM         CPM<td>MUA         Mith VED) - Three Phase Only         MIDE         CCM With Phanes           TAG         Fe-EX         C112-EDD Damper         0.400         1657         0.400         1678         1           MUA         I - Separate IZOV Wining Phaces         0.400         1679         0.400         1687         1         &lt;</td></td></thd<></thdish<>	EF-EX         DU130HFA         3262         1.300         1332         2.000           Pish         DU12HFA         600         0.400         I.657         0.350           FMA         INFORMATION         J.00490         I.657         0.350         0.350           FMA         INFORMATION         J.00493         Anula         0.400         I.657         0.350           FMA         INFORMATION         J.00483         PLOUSING         DEJICH         D.400         I.67         E59.           MUA         Anuent model         Anuent on 0.100VC Reference Speed Control (NIDEC         I.112-BDD Damper         0.400         I.67         0.400         I.67         E59.           Dish         I.112-BDD Damper         O         O.100VC Reference Speed Control (NIDEC         I.112-BDD Damper         I.112-BDD Damper	FE-EX         DU180HFA         3262         1.300         1332         2.000         1.000           I - EXPARE         Comparison         CPM         MIDE         CPM         MIDE         CPM         MIDE           I - EXPARE         Comparison         CPM         CPM <td>MUA         Mith VED) - Three Phase Only         MIDE         CCM With Phanes           TAG         Fe-EX         C112-EDD Damper         0.400         1657         0.400         1678         1           MUA         I - Separate IZOV Wining Phaces         0.400         1679         0.400         1687         1         &lt;</td>	MUA         Mith VED) - Three Phase Only         MIDE         CCM With Phanes           TAG         Fe-EX         C112-EDD Damper         0.400         1657         0.400         1678         1           MUA         I - Separate IZOV Wining Phaces         0.400         1679         0.400         1687         1         <

H"000.6 × 3"000.4 × W"000.4	Rall		# ٤	
H"000.21 × 21.000'L × 15.000'L	Curb	S81 6Z	8 #	3
H"000.02 × 1"002 × 1"002 × 1"002 × 1	Curb	581 SZ	ζ#	7
26.500"W × 26.500"L × 20.000"H Vented Hinged	Curb	587 I t+	τ#	ĩ
JZIS	METT	MEIGHT	EAN NAT	.ON
			sa a	<i>anp</i>
		A	NΜ	ε

DISCHARGE SIDE

DAMPER

U IVAXE

SUPPLY

(HZID) NAT TZUAHXE - ATHSTUD S# NAT

λES

УТІVАЯӘ РАМРЕR

TSUAHX3

NUON WALL

SEY

CUP SREASE

usia z

I EE-EX

ÐAT

SAIROSSADDA NAT

NAT UNIT ON.

#### **EEATURES:**

DAMPER DAMPER


2005 MOUNTED FANS


- VARIABLE SPEED CONTROL S0210 -

- INTERNAL WIRING

- WEATHERPROOF DISCONNECT

SNOTIdO








# Ceiling Cassette Single Zone Outdoor Unit (ODU) - LUU367HV










enil muts0 🗚 Piping Direction

Symbols


5-1.D. Ø 20 holes for drain connection









∀





.oN	Part Name	Description
ŀ	teltu0 niA	-
2	Power and communication cable Hole	-
3	aas Pipe Connection	Flare joint
4	Liquid Pipe Connection	Flare joint
ç	elbnsH	-
9	Pipe routing hole (tront)	-
L	Pipe routing hole (side)	-
8	Pipe routing hole (back)	-

#### DIMENSIONS






Fig. 1 – Dimensions 50HCQ 04–06 (Sheet 1 of 2) 28

C10559

ALL DEPICTIONS, DIMENSIONS, MEASUREMENTS AND ALL OTHER INFORMATION CONTAINED IN THESE DRAWINGS ARE FOR ILLUSTRATION PURPOSES ONLY AND MUST BE VERIFIED IN THE FIELD BY thyssenkrupp ELEVATOR CORPORATION. IN NO EVENT WILL thyssenkrupp ELEVATOR CORPORATION BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR INDIRECT DAMAGES (INCLUDING BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, DELAY, BUSINESS INTERRUPTION,) ARISING OUT OF THE USE OF THESE DRAWINGS, THE INABILITY TO USE THESE DRAWINGS (INCLUDING ANY INFORMATION CONTAINED THEREIN), OR ANY TRANSACTIONS RELATED TO THE USE OF THESE DRAWINGS. BECAUSE SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU. IN SUCH STATES, thyssenkrupp ELEVATOR CORPORATION'S LIABILITY IS LIMITED TO THE GREATEST EXTENT PERMITTED BY LAW.

ELEVATOR DESIGNATION	DRIVE HP	DRIVE AMPS	Controller Amps	TOTAL AMPS (RUNNING)	MAX UP ACC. AMPS (FULL LOAD)	SHORT CIRCUIT CURRENT RATING AMPS (AT 600V OR LESS)	REGEN KW- HI SPEED	REGEN KW- DECEL
Х	60R	16.7	3.0	20	29.1	25,000	6.8	9.6

NOTE : THE ELECTRICAL PARAMETERS ABOVE ARE BASED ON 480 V. WITHOUT A TRANSFORMER.

CONSTRUCTION WEIGHTS							
FACTORY PLATFORM WEIGHT	262 LBS.						
SLING WEIGHT (X-HD, STILE, SAFETY DEVICE, SAFETY CHANNELS & GUIDES)	1,103 LBS.						
CONSTRUCTION CAR TOP WEIGHT (CAR TOP + 500)	662 LBS.						
TOTAL TEMPORARY CWT. WT. REQUIRED	1,365 LBS.						
CWT. FRAME WEIGHT (FRAME, SHOES, SHEAVE, SAFETY, ETC.)	583 LBS.						
TEMPORARY FILLER WEIGHT	782 LBS.						
TEMPORARY FILLER HEIGHT (STEEL)	13 IN						

## TRACTION ELEVATOR CONTRACT DATA

		RACTION		٧A	10
ELEVATOR NUMBER		Х			E FOL
TYPE		PASSENGER	1		MPLE UMB, PF
CLASS	DESIGNED	FOR CLASS "A" FREIGHT LOAD	DING 2.	ADEC	QUATE
CAPACITY		3,500 LBS.	3.		TWAY E JRES).
MAX. UNIT LOAD		875 LBS.	4.		ightś / Ode).
MAX. AXLE LOAD		875 LBS.	5.	SEPA	RATE
MAX. SUSTAINING LOAD		3,500 LBS.			/INALS RM CIRC
SPEED		200 FPM	6		IDBY PO
OPERATION		TAC32T	0.	PROT	FECTIVE
STOPS		Х			Jireme Unding
HOISTWAY ENTRANCES		LH/RH/CO			NECTED VATOR
CAR DOORS	SIN	IGLE SPEED (PWD)	7.	AN E	NCLOS
STILE		F6.75 X 5.47			32° F., FACE. N
CROSSHEAD		F7 X 6.26	•		UNTIL E OPERL
SAFETY PLANK		F8.75 X 11.48		ENTF	RANCE
CAR GUIDE TYPE		SLIDE			gh ope Frame
BALANCE WEIGHTS		N/A LBS.		FRAM	IES AR
CAR SAFETY		FLEX-CLAMP			E: MUS KE SEN
GOVERNOR		CAR		(FOR	SECUF
MACHINE		5001CJ002	_		
DRIVE SHEAVE DIA.		4.41 IN. [112 mm]	_		ſ,
ISOLATION		STANDARD		>	┛ ┛
FULL LOAD MASS		15,718 LBS.			
CONTROL		VVVF			KIMUM V
POWER SUPPLY	48	30 V. 3 PH. 60 CYC.	<u> </u>		
HOIST BELTS		(4) 42.5 x 3.1 mm	_	OTE A:	ALL
GOVERNOR ROPE		1/4 IN. 8 X 19 [6.5mm]		UIL D.	HO
(PREFORMED)	. ,	ARRINGTON-IWRC	N	OTE C:	ELE SHO
COMPENSATION CHAIN		2) WF075			ŨNI
(WHISPER-FLEX)	`	LBS./FT.) PER CHAIN			_
CAR BUFFER TYPE	(0.73	OIL	<u> </u>		+
CAR BUFFER STROKE	(2)	2 3/4 IN.			
	(1)	OIL		DATE	:
CWT. BUFFER TYPE	(1)		_	DATE	
CWT. BUFFER STROKE		2 3/4 IN.			
CWT. STILE LENGTH		11'-1 1/2"	_		
CWT. GUIDE TYPES	(00)	SLIDE			
CWT. FILLER TYPE-SOLID	(89)	165CPV002			
CWT. FILLER TYPE-SPLIT	(0)	165CPV008	FC	)r:	
CAVITY FILLERS	(5)	165CPV005	_	DDRE	SS:
CWT. FILLER STACK HEIGHT		94 IN.		TY:	
CWT. PERCENTAGE		45.00%		-	ECT:
TOTAL FILLER WEIGHT		5,527 LBS.	GE	:NER	AL CC
TOTAL CWT. WEIGHT		6,091 LBS.	ты		WING A
TOTAL CAR WEIGHT W/ FLOORING		4,341 LBS.	NOT	T BE M	ADE PL
FLOORING WT. BY OTHERS		0	DIR	ECTL	Y OR
EST. CAB WEIGHT W/ FINISHES & DOOR OPERATOR		2,476 LBS.			
CAB TYPE		TKAP			thy
CAB FINISHES BY OTHERS		N/A			ના
MACHINE WEIGHT & FRAME		1,110 LBS.		RAWN	DA
CAR GUIDE RAILS		15 LBS./FT.		JAVVIN	DA
CWT. GUIDE RAILS		8 LBS./FT.		ΧХ	X/XX

LLOWING CONDITIONS MUST BE MET BEFORE INSTALLATION IS ETED, AND ARE NOT INCLUDED IN THE ELEVATOR CONTRACT:

PROPERLY-VENTILATED HOISTWAY (ACCORDING TO CODE AND SIZES SHOWN).

E SUPPORT FOR MACHINE BEAMS, GUIDE RAIL BRACKETS, AND BUFFERS (FOR REACTIONS SHOWN). BARRICADES (ALL CUTTING AND PATCHING TO INSTALL HOISTWAY ENTRANCES, SILLS, AND HALL

AND SWITCH, CONVENIENCE OUTLETS OF THE GFCI TYPE PER NEC, PIT LADDER PER CAR (ACCORDING NOTE: MUST BE CLEAR OF ALL ELEVATOR EQUIPMENT.

120 VOLT, 15 AMP. BRANCH CIRCUITS, ALONG WITH TELEPHONE CIRCUIT WHEN REQUIRED, TO S OF EACH REQUIRED CONTROLLER (AS LOCATED ON PLAN VIEW) FOR THE FOLLOWING: - CAR LIGHT AND CUIT WITH RECEPTACLES OF THE GFCI TYPE PER NEC - GROUP CONTROL WHEN REQUIRED NOTE: IF POWER IS SUPPLIED TO THE ELEVATOR, GROUP CONTROL CIRCUIT MUST BE STANDBY POWER BACKED. IRCUIT CONDUCTOR SIZING, MATERIALS, AND INSULATION (INCLUDING BRANCH CIRCUIT OVERCURRENT VE DEVICE) TO COMPLY WITH ALL LOCAL ELECTRICAL CODES (SEE "ELECTRICAL POWER IENTS"). NOTE: ALSO, A FOURTH WIRE OF SAME SIZE AS THREE PHASE WIRES IS REQUIRED FOR IG PURPOSES TO MINIMIZE ELECTRICAL NOISE INTERFERENCE. THE GROUNDING WIRE MUST BE ED TO THE BUILDINGS ELECTRICAL SYSTEMS GROUND. NOTE: IF STANDBY POWER IS REQUIRED, SEE R STANDBY POWER OPERATION".

SED CONTROLLER ROOM AREA (ACCORDING TO CODE), WITH ADEQUATE LIGHT, HEAT, VENTILATION , MAX. 122° F. WITH NON-CONDENSING HUMIDITY OF 20%-90%), AND SEALED CONCRETE FLOOR SLAB NOTE: MUST PROVIDE ADEQUATE DOOR SIZE TO ALLOW INSTALLATION OF EQUIPMENT - OR LEAVE WALL EQUIPMENT IS IN PLACE.

LY VENTED HOISTWAY AND MAINTAINED BET. 32° F. AND 122° F. 20% - 90% HUMIDITY

WALLS WITH LINTELS, NOTE: MUST BE PROVIDED AFTER ENTRANCE FRAMES ARE SET - OR LEAVE A ENING 1'-3" WIDER AND 1'-3" HIGHER THAN THE FRAME OPENING; FOLLOW INSTALLATION PROCEDURES E TO WALL INTERFACE TO MAINTAIN LABELED CONSTRUCTION. FILL IN AROUND FRAMES AFTER THE RESET. POCKETS IN CORRIDOR WALL (PER FIXTURE DRAWINGS) FOR HALL FIXTURES. ST BE LOCATED AS DIRECTED BY ELEVATOR CONTRACTOR

NSORS (AS REQUIRED). 12. CONDUIT AND WIRING FROM HOISTWAY TO ELEVATOR MONITORING PANELS IRITY, LIFE SAFETY, OR FIRE REQUIREMENTS).

F	RAIL FORCES		F <sub>1</sub>		$F_2$	
1	LOADING OR UNLOADING		595 LB.	343 LB.		
2						
_						
	FORCE ON EACH GUIDE		CAR			
TO SAFETY	APPLICATION.	8,	154 LBS.			
LL REACTIO	INS INCLUDE ALLOWANCE FOR IMPACT.					
iyssenkrupp B IOISTWAY O	ELEVATOR TO BE NOTIFIED OF ANY CHANGE TO I R MACHINE ROOM DESIGN PRIOR TO FABRICATIO	ELEVATOR ON OF ELEVA	TOR EQUIPMENT.			
HOWN, LAY	ESIGN AND FABRICATION BASED ON ESTIMATED OUT APPROVAL WILL BE CONSTRUED AS FINAL ( ERWISE NOTIFIED.					
SYM.	REVI	SION			BY	CHKD
	DO NOT SCALE TH	HIS DR/	AWING			
EL	EVATOR CONTRACTOR					
tł	nyssenkrupp ELEVATOR					
X	XX					
X	XX					

XXX XXX

ONTRACTOR: XXX

EBN1039


AND ALL INFORMATION THEREON IS THE PROPRIETARY PROPERTY OF thyssenkrupp ELEVATOR AND MUS UBLIC OR COPIED. THIS DRAWING IS LOANED SUBJECT TO RETURN ON DEMAND AND IS NOT TO BE USED INDIRECTLY, IN ANY MANNER DETRIMENTAL TO THE INTEREST OF thyssenkrupp ELEVATOR


yssenkrupp Elevator Corporation



#### ( thyssenkrupp

ATE	CHKD.	JOB NUMBER	REV.	SH	EET	NO.
X/XX	ХХ	XXX		х	OF	х





NOTE	1: TH
	HO
NOTE	2: AD
NOTE	3: IF I
	OR
NOTE	4: R1

= DUCT RISER ABV. LADDER									
S = PIT LIGHT SWITCH							FOR		
= TRAVELING CABLE							FOR:		
<ul> <li>RAIL BRACKET MOUNTING SURFACE</li> <li>H.S = HALL STATION</li> </ul>							THIS DRAWING AND ALL INFORMATION THEREON IS THE PROPRIETARY PROPERTY OF	tł	iysse
 D.B.G. = DIST. BET. GUIDES							THYSSENKRUPP ELEVATOR AND MUST NOT BE MADE PUBLIC OR COPIED. THIS DRAWING IS LOANED		
B.T.B. = BACK TO BACK RAILS P.U. = PICK UP F.O.R. = FACE OF RAIL							SUBJECT TO RETURN ON DEMAND AND IS NOT TO BE USED, DIRECTLY OR INDIRECTLY, IN ANY WAY DETRIMENTAL TO THE INTEREST OF THYSSENKRUPP ELEVATOR.	DRAWN	D
C.R.L. = CAR RIDING LANTERN									X/
H.A. = HOISTWAY ACCESS	J	DATE	SYM.	REVISION	BY	CHKD.	DO NOT SCALE THIS DRAWING		

R4 R5 R6

PIT FLOOR REACTIONS												
DN	s	TATIC WT. OF RAILS FOR 150'-0" TRAVEL	STATIC WT. OF MACHIN DOUBLE THE TENSION		TOTAL F	PIT FLOOR REACTIONS						
		1,363 LBS.	7,497 LB	S.		8,860 LBS.						
		1,363 LBS.	7,228 LB	S.	8,591 LBS.							
		2,556 LBS.	9,185 LBS.		11,741 LBS.							
2,556 LBS.			9,191 LB	S.	11,747 LBS.							
	BUFFER REACTIONS [SEE NOTE 4]											
	200 F.P.M.		350 F.P.M.	500 F.F	Р.М.	600 F.P.M.						
	R1	R1 0 LBS. 48,350 LBS. 56,500 LBS.		_BS.	45,350 LBS.							
	R7 17,100 LBS.		0 LBS.	0 LBS	S.	0 LBS.						
	R2	26,700 LBS.	38,150 LBS.	44,950 l	BS.	36,100 LBS.						

HE 4 1/2" RETRACTABLE LADDER IS STANDARD WITH 3500 LB. CAPACITY. A NOTCH IN THE DISTWAY WALL WILL BE REQUIRED WITH THE 4 1/2" NON-RETRACTABLE LADDER. DD 1" TO HOISTWAY WIDTH WHEN TRAVEL EXCEEDS 100'. DRYWALL CONSTRUCTION, INSTALL WALL AFTER ENTRANCE FRAMES ARE SET. IF CONCRETE R MASONRY CONSTRUCTION, LEAVE ROUGH OPENING AS SPECIFIED. 1 IS FOR 1 CAR BUFFER, R7 IS FOR 2 CAR BUFFERS.

EBN1051


#### yssenkrupp Elevator Corporation




#### () thyssenkrupp

DATE	CHKD.	JOB NUMBER	REV.	SHEET NO.
X/X/XX				OF


CLEAR INSIDE DIMENSIONS								
PANEL TYPE WIDTH DEPTH AREA								
STEEL SHELL	6'-9"	5'-5 1/2"	36.84 SQ. FT.					
1/2" PANEL	6'-8"	5'-5"	36.11 SQ. FT.					
7/8" PANEL	6'-7 1/4"	5'-4 5/8"	35.57 SQ. FT.					




8'-6" HOISTV	VAY	ł						
ŀ		4-2 1/16"						
CAR		CWT.						
" B.T.B. CAR	RAILS	/						
	3'-(	9 1/16"						
CAR		1						
	 T.C	MACHINE ASSEMBLY MACHINE BITB. OF CAR RAILS MACHINE MACHINE BITB. OF CAR RAILS CAR RAILS BITB. OF CAR RAILS CAR RAILS BITB. OF CAR RAILS CAR RAILS	<u>-</u>					
			<del></del>					
	) PLAN							
ALL WILL E DD 1" TO H DRYWALL ASONRY C ONTROLLE	BE REQUIRI IOISTWAY CONSTRU ONSTRUCT ER [400 LBS	LE LADDER IS STANDARD WITH 2500 LB. CAPACITY. A NOTC ED WITH THE 4 1/2" NON-RETRACTABLE LADDER. MIDTH WHEN TRAVEL EXCEEDS 100'. ICTION, INSTALL WALL AFTER ENTRANCE FRAMES ARE SET. 'ION, LEAVE ROUGH OPENING AS SPECIFIED. E.] IS TO BE JAMB MOUNTED AT THE TOP LANDING. (TYP.) ILL AT THE TOP LANDING FOR FRAME AND CONTROLLER INS	IF CONC	RETE OR				
				EBN1049				
vssenkrupp Elevator Corporation (Kingstein Krupp)								
DATE	CHKD.	JOB NUMBER	REV.	SHEET NO.				
				OF				



DATE	CHKD.	JOB NUMBER	REV.	SHEET NO.
X/X/XX				OF





The following items must be performed or provided at no cost to Otis Elevator Company ("OTIS") by the Owner or General Contractor or their agents in accordance with governing codes. The price and installation schedule of Otis is based on these job-site conditions existing at the beginning and during the installation of the elevator equipment. Failure to provide the items specified in this list will result in additional work performed by Otis Elevator beyond the scope of our contract causing installation delays. A change order will be submitted by Otis for materials and/or labor expended. All work must be performed per the applicable national and or local codes. General Prep/Work

- 1. Provide on-site storage area for elevator equipment as follows: dry and enclosed, provides roll-able access to the elevator hoistway at the ground level, located within 100 feet (30480mm) of the hoistway and is larger than 25 x 20 feet (7620mm x 6096mm) per elevator. Any warranties provided by Otis for elevator equipment are null and void if equipment is stored in a manner other than a dry enclosed building structure.
- 2. Provide sufficient on-site refuse containers for the proper disposal of elevator packaging material. Should sufficient refuse containers not be provided, disposal of packaging material shall become the responsibility of the owner.
- 3. Provide any cutouts to accommodate elevator equipment (troughing, venting, and hall fixtures), along with the patching/painting of walls, floors, or partitions together with finish painting of entrance doors and frames, if required. Hoistway & Pit Prep/Work
- 4. Provide and install a steel, I-beam shaped safety beam with a maximum flange width of 8 11/16" (220mm), from side wall to side wall at the top of the hoistway, capable of withstanding a minimumnet live load of 7500 lb (3402kg) per elevator. Reference Otis Layout for location. A 4" minimum clearance is required from top of beam to top of hoistway. If your jobsite voltage = 600VAC three phase or 240VAC single phase, and your controller is to be located in the hoistway entrance, one of the two option below must be done.
- Option 1: An additional steel I-beam needs to be provided and installed. It is to be located per the Otis layout & sized the same as the safety beam for the purpose of mounting the transformer provide by Otis (See overhead requirements). Option 2: No second beam needed. Place a transformer in an electrical room. The transformer must be mounted
- and wired as per the National Electrical Code (ANSI/NFPA 70). See Otis layout and fact sheets for details. 5. Provide a clear plumb hoistway with variations from the size shown on the Otis layout not to exceed -0"/+1"(25mm) and not less than the clear dimensions shown on the Otis layout
- 6. Provide adequate rail bracket supports, bracket spacing as required by governing code, from pit floor to top of hoistway to comply with the rail reaction forces detailed on the Otis Contract Layout. Provide adequate support for the top rail brackets at locations above the top landing as specified on the Otis Layout. Provide separator beams where required. Unless approved by Otis, rail-bracket attachment supports must be exposed and flush with the clear hoistway line.
- If the floor-to-floor height exceeds the maximum bracket spacing allowed by the elevator code, Otis requires some form of steel support to properly attach our guide rail brackets. The maximum allowed bracket spacing is indicated in the rail force and bracket detail table on the Otis layout. Any rail bracket mounting surfaces that are not in line with the finished hoistway dimension (i.e. the clear hoistway line) may need to be extended to meet the required distance. Otis agrees to provide guidance on this matter at the appropriate time.

If rail bracket embedded plates or inserts are provided by Otis they shall be installed by others in accordance with Otis documentation and instructions.

- If vertical tube steel is utilized as rail support, see the Otis layout for any specific requirements
- 7. Provide adequate support at all fastening points of each entrance. Provide plumb vertical surfaces for entrances and sill supports, one above the other, and square with the hoistway. Finish floor and grout, if required, between entrances and building sill line. For MRL installations, a horizontal support member is to be provided 20" (508mm) above the clear opening at the controller landing to support the entrance and controller components. If any other floor height exceeds 12'-0" (3657mm), a horizontal support member is to be provided 12" (305mm) above the clear opening. For MRL installations, if entrance finish protection is installed, a section of such protection must be removable to allow safe and convenient access to the Inspection & Test panel of the elevator.
- 8. Prior to the start of installation, provide a dry, properly framed, enclosed and vented hoistway in accordance with all applicable codes.
- 9. A.) Protection from Falls:

As required by the Occupational Safety and Health Administration (OSHA) 1926.502 B) (1-3) a freestanding removable barricade at each hoistway opening at each floor. Barricades shall be 42" (1067mm) high, with mid-rail and kick board, and withstand 200 lbs. (90.7kg) of vertical and horizontal pressure. B.) Protection from Falling Objects:

As required by the Occupational Safety and Health Administration (OSHA) 1926.502(j) hoistway protection from falling debris and other trades materials by either:

- 1.)Full entrance screening/mesh in front of all elevator entrances
- 2.)Secured/controlled access to all elevator lobbies (lock and key) with posted Notice "only elevator personnel beyond this protection."

Notes:

## Items A.) and B.) can be integrated systems.

Hoistway barricades and screening shall be constructed, maintained and removed by others.

- 10. Provide a pit floor designed to sustain vertical forces (based on safety impact) on car and counterweight rails and impact loads on car and counterweight buffers as shown on the Otis layout. The pit must be dry and clean. The elevator pit must have a floor drain or sump pump to prevent the accumulation of water. Location to be coordinated with Otis to avoid all elevator components and access areas. In areas requiring fire fighters emergency operation (FEO) a sump pump/drain shall be provided that shall have the capacity to remove a minimum of 11.4m3/h (3,000 gal/h) per elevator (ASME A17.1/CSA B44 latest applicable code year section 2.2.2.5). Otis recommends that the owner verify the drain or sump pump system is in compliance with all applicable codes and laws.
- 11. The front entrance wall at the main landing and top landing, is not to be constructed until after all elevator equipment is installed in the hoistway (the entire front wall - CLEAR HOISTWAY WIDTH - must be open for installation). Remaining front entrance walls are not to be constructed until after door frames and sills are in place. The rough openings, per sizes shown on the Otis layout, are required. Prior to the completion and turnover of the elevator(s), all entrance walls must be installed and rough openings filled in complete to maintain fire rated hoistway
- requirements. 12. Provide and install a fixed vertical iron ladder in each pit as required by governing code and located per Otis layout or as coordinated with Otis personnel. Ladder width and pit wall pocket requirements are shown in the pit plan view on the Otis layout.
- 13. Install permanent light fixture in each elevator pit with illumination of not less than 100 lx (10 fc) as measured at the pit floor. The light bulb(s) shall be externally guarded to prevent contact and accidental breakage. The light switch shall be so located as to be accessible from the pit ladder.
- 14. Glass used in hoistway construction must block 98% or more of incident full-spectrum ultraviolet radiation for the full height of the hoistway.
- 15. Provide and install guarding of counterweight in a multiple-elevator hoistway as required, when a counterweight is located between elevators, the counterweight runway shall be guarded on the side next to the adjacent elevator. The guarding must meet or exceed the requirements of ASME A17.1/CSA B44 latest applicable code year, section 2.3.2.3.

If an emergency door in a blind hoistway is required, provide an outward swinging single section type door with door closer and a self closing barrier per ASME A17.1/CSA B44 latest applicable code year, section 2.11.1.2. Contact your local Otis personnel for a detailed drawing (AAA26900D FMI) showing Otis specific requirements

MRL Machine Space Prep/Work

- 16. Maintain the temperature at the top of the hoistway (machine space) between 32° F (0° C) and 104° F (40° C). This space also includes the car controller which is mounted at the top landing. Relative humidity shall not to exceed 95% non-condensing. Provide ventilation to suit Otis heat release amounts as shown in Otis Confirmation of Power Supply form. Local codes may require tighter temperature ranges and higher ventilation levels. Please check with your local code authority for the exact requirements in your area. If your machinery space temperature exceeds this requirement, contact your local Otis sales representative for assistance.
- 17. Install a permanent light fixture at the top of the hoistway (machine space) of not less than 200-lux (19 fc) as measured at the level of the standing surface on the car when the elevator is at the top landing. Light switch is to be located in the hoistway per the Otis layout.
- 18. Install a permanent light fixture at the top landing entrance (control space), in the hall, of not less than 200-lux (19 fc) as measured at the floor level. Light switch is to be located close to the elevator entrance.

Control Room/Space and Machine Space Prep/Work

19. Provide a suitable control room/space(s) with access and ventilation in accordance with all applicable codes and regulations. The control room/space(s) shall be maintained at a temperature between 32F (0C) and 104F (40C) to be measured 6 feet (1830 mm) above the floor and 1 foot (305 mm) out from the front center of the car controller(s). Relative humidity is not to exceed 95% non-condensing. Provide ventilation to suit Otis heat release amounts as shown on the Otis Confirmation of Power Supply form. Local codes may require tighter temperature ranges and higher ventilation levels, please check with your local code authority for the exact requirements in your area. If your control room/space(s) temperatures exceed these requirements, contact your local Otis sales representative for assistance.

20. Provide illumination of control room/space(s) of not less than 200 LUX (19 FC) as measured at floor level. Light switch is to be located within 18" (157 mm) to the lock-jamb side of the access door to the control room/space(s). 21. Provide control room/space(s) with self-closing and self-locking doors with a group 2 locking device. In addition, ensure that all air gaps around the doors are sealed (i.e. threshold, weather stripping, etc.).

Relative humidity shall not to exceed 95% non-condensing. Provide ventilation to suit Otis heat release amounts as shown in Otis Confirmation of Power Supply form. If your machinery space temperature exceeds this requirement,

22. Maintain the temperature at the top of the hoistway (machine space) between 32° F (0° C) and 104° F (45° C). contact your local Otis sales representative for assistance.

23. Install a permanent light fixture at the top of the hoistway (machine space) of not less than 200-lux (19 fc) as measured at the level of the standing surface on the car when the elevator is at the top landing. Light switch is to be located in the hoistway per the Otis layout. Fire Prevention Prep/Work

24. Provide hoistway walls designed and constructed in accordance with the required fire rating (including those places where elevator fixture boxes, rail bracket fastenings, and any other penetration into the hoistway walls). 25. In the United States provide smoke detectors, located as required, with wiring from the sensing devices to the

controller(s) designated by Otis. A. For each group of elevators, provide a normally closed contact representing the smoke detector at the designated

return landing. B. For each group of elevators, provide a normally closed contact representing all smoke detectors located in lobbies, hoistways, or control rooms/spaces but not the smoke detector at the designated return landing (see above) or the smoke detectors as described below:

1) If a smoke detector is located in the hoistway at or below the lower of the two recall landings, it shall be wired to activate the same normally closed contact as the smoke detector located in the lobby at the lower of the two recall landings.

2) If the control room/space(s) are located at the designated return landing, the smoke detectors located therein shall be wired to activate the same normally closed contact as the smoke detector at the designated landing. C. Requirements for intermittently illuminating the fire hat visual signal in the car operating panel, either 1) or 2) must be selected.

1) For a single unit, or group of elevators having control room/space(s) and one common hoistway, provide one additional normally closed contact representing the control room/space(s) and hoistway smoke detectors. 2) If the group contains more than one hoistway, and hoistway smoke detectors are installed, provide one normally closed contact for each elevator. The contact is to represent the smoke detectors in the control

room/space(s) or hoistway containing that particular elevator.

26. In Canada provide smoke detectors, located as required, with wiring from the sensing devices to the controller(s) designated by Otis.

A. For each group of elevators, provide a normally closed contact representing the smoke detector at the designated

return landing and if provided, from the sensing device in the pit. B. For each group of elevators, provide a normally closed contact representing all smoke detectors located in elevator lobbies, but not the smoke detector at the designated return landing (see above), and if provided, from the sensing device in the top of the hoistway.

C. For each group of elevators, provide a normally closed contact representing the smoke detector in the elevator machine space.

D. If the control space is located at the designated return landing, the smoke detectors located therein shall be wired to activate the same normally closed contact as the smoke detector at the designated landing. For each group of elevators, provide in addition to the above, a normally closed contact representing the sensing devices in the pit or at the top of the hoistway (For the Fire Hat in the Elevator).

27. In the United States, if sprinklers are installed in the hoistway(s), or machine space(s), a means to automatically disconnect the main line power supply of the affected elevator and any other power supply used to move the elevator upon or prior to the application of water is required (unless prohibited by local code). Smoke detectors shall not be used to activate sprinklers in hoistway(s), or machinery spaces or to disconnect the mainline power supply.

In addition, when the Automatic Recovery Operation (ARO) is specified, the means provided to automatically disconnect power to the elevator shall be equipped with an additional auxiliary contact that is positively opened when power is removed from the elevator system. This automatically controlled mainline disconnect must be provided with all associated wiring and conduit to the controller.

28. Provide an "ABC" fire extinguisher, minimum 10 lbs for machine space, and located convenient to the top landing elevator entrance.

29. Provide control room/space(s) and door to code compliant fire-resistive construction Electrical Requirements

30. 3 Phase Power MRL - Provide a permanent three (3) phase electrical-feeder system with a separate equipment-grounding conductor terminating in the elevator controller located at the top landing or transformer located at the top of the hoistway. Permanent three (3) phase electrical-feeder to be terminated at the elevator controller or transformer at the start of installation of the top landing elevator entrance and the timing of connection to Otis controller shall be coordinated with the elevator installer. Feeder conductors and grounding conductor sized according to elevator current characteristics as shown on the Otis Confirmation of Power Supply form. Feeder conductors and grounding conductor must be copper. Provide a fused disconnect switch or circuit breaker capable of being locked in the open position, for each elevator per the National Electrical Code (ANSI/NFPA 70) or Canadian Electrical Code (C22.1) with feeder or branch wiring to elevator controller [NEC 620-51, 620-61(D), and 620-62] or [CEC Rule 38-013 (2) (a)] located at the point of power distribution in the building. The disconnecting means required by the National Electrical Code or Canadian Electrical Code CEC [Rule 38-051] shall be provided with all associated wiring and conduit to the elevator controller. Size of main contacts to suit elevator power characteristics. Fuses, if provided, are to be current limiting class J or equivalent. Circuit breakers, if provided, are to have current limiting characteristics equivalent to class J fuses. Fuses or circuit breakers are to be time delay to cover the full load up accelerating current. Accelerating current typically is the peak as indicated on the Otis Confirmation of Power Supply Form, and lasts for duration not to exceed 7 seconds. Feeder conductors and associated wiring to the controller to be sized to limit wiring voltage drop to 5% maximum when delivering elevator full load up accelerating current. The building power system used to operate the elevator(s) shall be capable of supplying non linear loads and be capable of absorbing the regenerated power listed on the Otis Confirmation of Power Supply form

Single Phase Power MRL - Provide a permanent single phase electrical-feeder system with a separate equipment-grounding conductor terminating to the transformer located at the top of the hoistway. Permanent single phase electrical-feeder to be terminated at the transformer at the start of installation of the top landing elevator entrance and the timing of connection to Otis controller shall be coordinated with the elevator installer. Feeder conductors and grounding conductor sized according to elevator current characteristics shown on the Otis Confirmation of Power Supply form. Feeder conductors and grounding conductor must be copper. Provide a fused disconnect switch or circuit breaker capable of being locked in the open position, for each elevator per the National Electrical Code (ANSI/NFPA 70) or Canadian Electrical Code (C22.1) with feeder or branch wiring to elevator controller [NEC 620-51, 620-61(D), and 620-62] or [CEC Rule 38-013 (2) (a)] located at the point of power distribution in the building. The disconnecting means required by the National Electrical Code or Canadian Electrical Code CEC [Rule 38-051] shall be provided with all associated wiring and conduit to the elevator controller. Size of main contacts to suit elevator power characteristics. Fuses, if provided, are to be current limiting class J or equivalent. Circuit breakers, if provided, are to have current limiting characteristics equivalent to class J fuses. Fuses or circuit breakers are to be time delay to cover the full load up accelerating current. Accelerating current typically is the peak as indicated on the Otis Confirmation of Power Supply Form, and lasts for duration not to exceed 7 seconds Feeder conductors and associated wiring to the controller to be sized to limit wiring voltage drop to 5% maximum when delivering elevator full load up accelerating current. The building power system used to operate the elevator(s) shall be capable of supplying non linear loads and be capable of absorbing the regenerated power listed on the Otis Confirmation of Power Supply form.

31. 3 Phase Power Control Room/Space - Provide a permanent three (3) phase electrical-feeder system with a separate equipment-grounding conductor terminating in the control room/space(s), located per Otis layout. Feeder conductors and grounding conductor sized according to elevator current characteristics as shown on the Otis Confirmation of Power Supply form. Feeder conductors and grounding conductor must be copper. A fused disconnect switch or circuit breaker capable of being locked in the open position, for each elevator per the National Electrical Code (ANSI/NFPA 70) or Canadian Electrical Code (C22.1) with feeder or branch wiring to controller [NEC 620-51, 620-61(D), and 620-62] or [CEC Rule 38-013(2)(a)]. The disconnecting means required by the National Electrical Code or Canadian Electrical Code CEC [Rule 38-051] shall be provided with all associated wiring and conduit to the controller. Size of main contacts to suit elevator power characteristics. Fuses are to be current limiting class RK1 or equivalent. Circuit breakers are to have current limiting characteristics equivalent to class RK1 fuses. Fuses or circuit breakers are to be time delay to cover the full load up accelerating current. Accelerating current typically is the peak as indicated on the Otis Confirmation of Power Supply Form, and lasts for duration not to exceed 7 seconds. Feeder conductors and associated wiring to the controller to be sized to limit wiring voltage drop to 5% maximum when delivering elevator full load up accelerating current. The building power system used to operate the elevator(s) shall be capable of supplying non linear loads and be capable of absorbing the regenerated power listed on the Otis Confirmation of Power Supply form.

Single Phase Power Control Room/Space - Provide a permanent single phase electrical-feeder system with a separate equipment-grounding conductor terminating in the control room/space(s), located per Otis layout. Feeder conductors and grounding conductor sized according to elevator current characteristics as shown on the Otis Confirmation of Power Supply form. Feeder conductors and grounding conductor must be copper. A fused disconnect switch or circuit breaker capable of being locked in the open position, for each elevator per the National Electrical Code (ANSI/NFPA 70) or Canadian Electrical Code (C22.1) with feeder or branch wiring to controller [NEC 620-51, 620-61(D), and 620-62] or [CEC Rule 38-013(2)(a)]. The disconnecting means required by the National Electrical Code or Canadian Electrical Code CEC [Rule 38-051] shall be provided with all associated wiring and conduit to the controller. Size of main contacts to suit elevator power characteristics. Fuses are to be current limiting class RK1 or equivalent. Circuit breakers are to have current limiting characteristics equivalent to class RK1 fuses. Fuses or circuit breakers are to be time delay to cover the full load up accelerating current. Accelerating current typically is the peak as indicated on the Otis Confirmation of Power Supply Form, and lasts for duration not to exceed 7 seconds. Feeder conductors and associated wiring to the controller to be sized to limit wiring voltage drop to 5% maximum when delivering elevator full load up accelerating current. The building power system used to operate the elevator(s) shall be capable of supplying non linear loads and be capable of absorbing the regenerated power listed on the Otis Confirmation of Power Supply form.

32. Provide a dedicated 125 volt, 15 ampere single-phase branch circuit with a fused disconnect switch or circuit breaker located at the point of power distribution in the building. The fused disconnect or circuit breaker shall be capable of being locked in the open position. This branch circuit supplies the car lights, car top receptacle, auxiliary lighting power source and ventilation on each car in compliance with the National Electrical Code [NEC620-53] or Canadian Electrical Code [CEC Rule 38-053]. Termination of this branch circuit shall be in the elevator controller located at the top landing and shall be connected at the same time as the permanent three (3) phase power referenced in the previous paragraph.

permanently installed pit sump pump shall not require GFCI protection.

35. Provide one (1) dedicated outside telephone line, per elevator, and terminated at the controller designated by the Otis construction superintendent. Reference the A17.1 code and the Otis power of confirmation letter for specific requirements.

36. In areas under the jurisdiction of AMSE A17.1-2004/CSA B44 or later where the elevator travel is greater than or equal to 60 feet /18 meters, provide two-way voice communications means that shall enable emergency personnel within the building to establish communications to each car individually without intervention by a person within the car. The communication means shall override communications to the outside of the building and once established shall only be terminated by emergency personnel outside the car. Refer to ASME A17.1/CSA B44 latest applicable code year, section 2.27.1.1.4 for exact requirements.

37. [Optional] For elevators having an intra building intercom, provide a separate 120 volt, 15 ampere, single phase power supply with fused SPST disconnect switch or circuit breaker, located as required for inter-communicating system power supply. Circuit to be arranged for feeding from the building emergency lighting supply if provided. Conduit and wiring for remotely located inter-communicating stations.

38. [Optional] For installations having emergency (standby) power, provide the standby power unit and means for starting it. The emergency (standby) power unit shall deliver to the elevator via disconnect switches in the building power distribution location or disconnect switches in the control room/space(s), sufficient power to operate one or more elevators at a time at full rated speed, and rated load. An automatic power transfer switch for each power feeder to monitor both normal and emergency (standby) power conditions and to perform the transfer from one to the other. Switch to have two sets of normally closed dry contacts, one to be open when the switch is in the emergency (standby) power position; the other to open upon initiation of power transfer and to close when transfer is complete. Switch to have an inhibit function which will delay transfer to normal and/or emergency (standby) power by an adjustable period of 0 - 300 seconds. Switch shall have a phase monitor feature, which prohibits the transfer of power between "live" sources unless the sources are in phase with each other. If a shunt trip device is provided, an additional normally closed contact, with all associated wiring and conduit to the controller, is required from the emergency (standby) power source. The emergency (standby) power system provided shall comply with ANSI/NFPA 70 requirements 620.91. The table in section "ELEVATOR REGENERATIVE POWER REQUIREMENTS", on the Otis Confirmation of Power Supply form, contains the elevator system power regenerated under an overhauling load. The information contained in the form is to be used to determine regenerative power absorption capability for the emergency (standby) power distribution system. Note: The building Emergency (Standby Power) Generator system used to operate the elevator(s) shall be capable of

supplying non-linear loads.

39. [Optional] Compass™ Dispatching System - a dedicated 125 volt 20 ampere single-phase power supply with SPST fused disconnect switch or circuit breaker. The fused disconnect or circuit breaker shall be capable of being locked in the open position and located upstream of the elevator equipment. This disconnect or circuit breaker must be in sight of the Compass<sup>™</sup> Dispatching System equipment. MRL Configuration (controller located in hoistway entrance) with Compass™ - If Compass is required and the controller is to be located in the hoistway entrance, an electrical room must be provided for the Compass Dispatching System equipment within sight of the entrance controller. Contact your local Otis representative for details.

[OPTIONAL] FIRE SERVICE ACCESS ELEVATORS (FSAE) FSAE Hoistway & Pit Prep/Work

FSAE Machine Room Prep/Work

41. Provide climate control and ventilation with monitoring equipment FSAE Fire Protection Prep/Work

out any of the foregoing requirements.

THIS WORK AND THE INFORMATION IT CONTAINS ARE THE PROPERTY OF OTIS ELEVATOR COMPANY ("OTIS"). IT IS DELIVERED TO OTHERS ON THE EXPRESS CONDITION TH IT WILL BE USED ONLY FOR OR ON BEHALF OF OTIS: THAT NEITHER IT NOR THE INFORMATION IT CONTAINS WILL BE REPRODUCED OR DISCLOSED. IN WHOLE OR IN PART. WITHOUT THE PRIOR WRITTEN CONSENT OF OTIS: AND THAT ON DEMAND IT AND ANY COPIES WILL BE PROMPTLY RETURNED TO OTIS.

UNPUBLISHED WORK (C) OTIS ELEVATOR COMPANY 2004 ALL RIGHTS RESERVED.

33. All 125 volt, 15 or 20 ampere single-phase receptacles installed in pits, machine spaces, control rooms/space(s) shall be of the ground-fault circuit-interrupter type (GFCI). A dedicated single-phase receptacle supplying a


34. Provide electric power for lights, tools, welding, hoisting, etc. during installation with sufficient power for starting, testing and adjusting the elevator. Provide a 220 volt, 30 ampere single-phase 4 wire electrical supply for platform operation during construction, available at the start of elevator installation.


40. Provide all hoistways to meet structural code requirements for Fire Service Access Elevators as per IBC and NFPA

42. Comply with NFPA requirements relative to hoistway pressurization and sprinkler prohibition.


You agree to indemnify and save Otis harmless against any and all liability and costs arising out of your failure to carry

	Gen2®
	3500# @ 150 F.P.M. SEISMIC 0/1
	<b>Otis</b> A United Technologies Company
	DWG. NO.: G2S 3500-PWBO
E	BUILDING Town Project
AT	LOCATION Arizona
	CONT. WITH
	OWNER
	ARCHT.
	CONTRACT NO.
























EXPRESS DRAW: WEB:19








	RA	IL FORC	E & BR		
		R2 VY R1	F	R2	
		VX —		/Y	
		SEE	NOTES 6 & 7 R1	518 lbs	
SUPPORT			R2	90 lbs	
S)			VX	N/A	
D ON THE OF CWT.)	CAR			N/A	
		MAXIMUM	SPACING	12' 0"	
		F	RAIL SIZE	1-1/2	
			R1	265 lbs	
			R2 VX	19 lbs N/A	
	CWT		VA VY	N/A	
		MAXIMUM I		12' 0"	
			SPACING	2	
		DEH	R1	660 lbs	
	(DEAD	END HITCH)	R2	1590 lbs	
				JES ABOVE ARE ENTIRE GROUP	
	TO BE OTHEF EXCEE	LOCATED 1 R INTERMED D THE MAX	4' 0" FROM IATE SUPPO IMUM BRAC	JPPORT LOCA PIT FLOOR. AL ORTS CANNOT KET SPACING SPACING DET	IN
	CWT R R2 = L0 REQUI	1 = SAFETY 1 = LOADIN DADING OR REMENTS F	g or runn Running Or rail bf	ING	
		DRT (NOT B) CTION NOT TO		8"	
	BASED	ON HORIZON	ITAL RAIL FO	RCES.	
		тшс	APPRC		
				EMENT AND	ROVED
SIGN				DATE:	
ELEVA COND NEITH DISCL AND T OTIS.	ATOR COM ITION THA IER IT NOR OSED. IN V THAT ON D	Pany ("otis"). I T it will be us The informat Vhole or in pa Emand it and a	T IS DELIVERED ED ONLY FOR ( TION IT CONTAI ART, WITHOUT ANY COPIES W	INS ARE THE PROPI O TO OTHERS ON TH OR ON BEHALF OF ( NS WILL BE REPRO THE WRITTEN CONS ILL BE PROMPTLY F	HE EXPRESS OTIS; THAT DUCED OR SENT OF OTIS;
	BLISHED W	<u> </u>	ELEVATOR CC	DMPANY 2004	
			Ger	12 <sup>®</sup>	
	485	350( S	<b>)# @ 1</b> Seism	50 F.P.N IC 0/1	
		<b>Otis</b> A United 1	-	s Company	
DWC	G. NO.:	G2S	3500	-EL	
		Town Pro			
		Arizon	<i>,</i>		
	IT. WIT	<sup>-</sup> H			
	NER				
ARC					
	ITRAC	I INU.			





# **TOP LANDING ENTRANCE REQUIREMENTS**

OTIS WALL 7

M1 (RECESSED FRAME IN MASC

NOT M1

# (MUST BE LOCATED AT THE TOP ENTRANCE)

# MRL CONTROLLER MINIMUM DEPTH REQUIREMENTS

TYPE	MINIMUM WALL DEPTH	MINIMUM JAMB DEPTH
Sonry Wall)	_	8 5/8"
1	7"	-



EXPRESS DRAW: WEB:19

## Dedicated to People Flow<sup>™</sup> **KONE**

MACHINE ROOM-LESS PERFORMANCE IN A HYDRAULIC ELEVATOR HOISTWAY

KONE EcoSpace<sup>™</sup>

# The revolutionary machine room-less elevator concept

is the permanent-magnet, gearless KONE EcoDisc<sup>®</sup> motor. KONE's machine room-less (MRL) technology eliminates the need for a machine or control room by attaching the hoisting machine to the guide rail, and placing all control and logic components within the confines of the hoistway.

#### **Greater efficiency**

The revolutionary KONE EcoDisc weighs less than half of a conventional geared traction machine, and has only one moving part. Its efficiency is three times that of a hydraulic power unit and uses 70% less energy – a savings which can represent half or more of the annual cost of the elevator operation.

#### Space savings

KONE EcoSpace does not need a separate machine room thanks to the KONE EcoDisc hoisting motor, which is so compact that it can be located in the hoistway. There is no need for a control room as the KONE EcoSpace control and logic components fit inside the wall of the top elevator landing.

#### Simplified installation

The whole elevator fits inside the shaft, simplifying the building interface and saving space for more profitable use. This also speeds up the installation process, since no scaffolding or cranage is needed.

#### **Destination control**

The KONE Polaris<sup>™</sup> destination control system can significantly improve convenience in your building while enhancing the appearance of your lobby.

# KONE EcoDisc – gearless energy saver

KONE took the technological lead in the elevator industry by developing the KONE EcoDisc hoisting machine. With over 440,000 installations worldwide, KONE continues to develop machine room-less technology while focusing on energy and space efficiency, reliability and excellent ride comfort. The KONE EcoDisc is the core technology for all KONE elevators. It employs a permanent-magnet synchronous motor, frequency control and low-friction gearless construction.

#### **Regenerative System**

The energy consumption of a KONE EcoSpace can be further reduced with the installation of a regenerative drive. KONE's regenerative drive solution:

- Recovers excess energy from the elevator when an empty car travels upward or a full car travels downward
- Can recover up to 25% of the total energy used by an elevator
- Produces clean and safe energy that does not damage the network


KONE's machine room-less technology has successfully helped projects earn LEED credits in the Energy & Atmosphere and Innovation & Design categories.



#### **Product material content**

KONE EcoSpace is mainly composed of steel and cast iron.

#### Material weight %



Aluminum	0.5
Cast iron	6.3
Copper	0.9
Stainless steel	0.0
Steel	73.4
Steel (zinc coated)	14.2
Plastics	0.9
Others	0.1
Electronics and	3.6
electromechanical	
components	

The metals, which are about 97% of the elevator material weight, are recyclable.

The product does not contain asbestos, paints containing lead or cadmium pigments, condensators containing PCBs or PCTs, ozone layer depleting chemicals such as CFCs, or chlorinated solvents. Mercury is not used in applications other than lighting and batteries. Cadmium stabilizers are not used in plastics.

# Aesthetic options for your new elevator

The KONE EcoSpace<sup>™</sup> elevator offers a wide selection of cabs, entrances and signalization to enhance the look of your building at an affordable price.

For KONE, the goal is to create the best possible user experience. A smooth ride and reliable performance ensure the ideal people flow, while the car interior design creates an aesthetically pleasing experience for each passenger.

For additional interior offerings, reference the KONE Design Collection Catalog or visit www.kone.us to create project-specific designs with the KONE Car Designer Tool.

# Handrails



**1.25" Round** in Brushed Aluminum, Stainless Steel with Satin finish



**2" Round** in Stainless Steel with Satin finish



**1.5" Flat** in Stainless Steel with Satin finish



**2" Flat** in Stainless Steel with Satin finish



**3" Flat** in Stainless Steel with Satin finish



**4" Flat** in Stainless Steel with Satin finish

# Ceilings

Several ceiling designs are available for KONE EcoSpace elevator cabs.



Panels – Polygal Translucent Frame – Brushed Aluminum Lighting – T-5 Fluorescent



**Panels** – Stainless Steel with Satin Finish **Lighting** – T-5 Fluorescent



Panels – Stainless Steel with Satin Finish Lighting – T-5 Fluorescent



Panels – Stainless Steel with Satin Finish Lighting – Round LED\*



**Panels** – Stainless Steel with Stain Finish **Lighting** – Square LED\*



Panels – Stainless Steel with Satin Finish Lighting – Rectangular LED\*

\*Six light fixtures for Passenger Shape and nine light fixtures for Service Shape.

# Walls

Choose from a wide variety of high-quality interior materials. Multiple combinations of wall and ceiling materials are available, allowing you to match virtually any lobby design.





#### To reduce our carbon footprint, KONE has begun using QR – or Quick Response – codes, which are an environmentally friendly alternative to printed materials.

Simply scan this QR code with your smartphone and you'll be taken to the KONE EcoSpace Toolbox where you can create project-specific CAD drawings, BIM models and CSI specifications quickly and easily online. Or just type in this shortened URL link – *bit.ly/estool*.

In addition, you can find our products with ARCAT at *www.arcat.com*.

#### **Color Finishes**

Color Finisnes	
<b>4757-60*</b>	4638-60*
Mystique Moonlight	Monterey Sun
<b>4798-60*</b>	ES2002T**
Burnished Ember	Honeytone Essence
<b>4813-60*</b>	<b>4744-60*</b>
Nickel Ev	Karratha Brush
<b>4746-60*</b>	<b>4669-60*</b>
Woolamai	Natural Tigris
<b>4623-60*</b>	WZ1001T**
Graphite Nebula	Red Dragon Bamboo
Metal Finishes	
6258*	<b>6312*</b>
Satin Brushed Gold	Mercury Stria*
6313*	6261*
Bronze Striaª	Satin Brushed Light Bronze
<b>6262*</b>	6277*
Satin Brushed Med. Bronze	Alumasteel
Scottish Quad Rigidized Stainless Steel	<sup>a</sup> Please note that Mercury Stria and Bronze Stria are only available for 8' tall cars.
Wood Finishes	-

<b>7850-60*</b>	<b>10776-60*</b>
Beigewood	Kensington Maple
7062-60*	<b>7919-38*</b>
Congo Spruce	Amber Cherry
<b>7054-60*</b>	<b>7039-60*</b>
Wild Cherry	Windsor Mahogany
<b>7949-38*</b>	<b>7040A-60*</b>
Asian Night	Figured Mahogany

#### **Pearlescent Finishes**

#### D487-07\* Pearl Silver LS

D485-07\* Pearl Bisque LS

Laminate Brands

\* Wilson Art \*\* Nevamar

# Signalization

KSS 140 vandal resistant signalization is impact, scratch, burn and splash resistant. KSS 570 signalization enhances the look of your elevator.




For additional aesthetic offerings, reference the KONE Design Collection Catalog or visit www.kone.us to create project-specific car designs, CAD drawings, BIM models and CSI specifications.

# KONE EcoSpace<sup>™</sup> Planning Guide


<b>Max Travel</b> <sup>(8)</sup> 150 ft. (45.7 m)					A	A SEISMIC	В	С	D	E
Max Landings <sup>(8)</sup>			CAPACITY LBS. (kg)	OPENING TYPE	HOISTWAY WIDTH (mm)	HOISTWAY WIDTH (mm)	HOISTWAY DEPTH (mm)	INTERIOR WIDTH (mm)	INTERIOR DEPTH (mm)	DOOR WIDTH (mm)
15		ER	2000 (907) 2500 (1134)	SSP SSP-CO	7'-4" (2235) 8'-4" (2540)	7'-8" (2337) 8'-8" (2642)	5'-9" (1753) 5'-9" (1753)	5'-8" (1727) 6'-8" (2032)	4'-3" (1295) 4'-3" (1295)	3'-0" (914) 3'-6" (1067)
Speed <sup>(8,9,10)</sup>	Opening	PASSENGER	3000 (1134)	SSP-CO	8'-4" (2340) 8'-6" (2591)	8'-8" (2642)	6'-3" (1905)	6'-8" (2032)	4-3 (1293) 5'-0" (1524)	3'-6" (1067)
150, 200, 350 fpm (.75, 1.0, 1.78 m/s)	Front Ope	PASS	3500 (1588) 4000 (1814)	SSP-CO CO	8'-6" (2591) 9'-4" (2845)	8'-8" (2642) 9'-4" (2845)	6'-11" (2108) 6'-11" (2108)	6'-8" (2032) 7'-5 <sup>13</sup> ⁄ <sub>16</sub> " (2281)	5'-6 <sup>3</sup> ⁄16" (1681) 5'-6 <sup>3</sup> ⁄16" (1681)	3'-6" (1067) 4'-0" (1219)
<b>Car Height F</b> 8, 9 or 10 ft.	Fro	SERVICE	4000 (1814) 4500 (2041) 5000 (2268)	2SP 2SP 2SP	7'-4" (2235) 7'-4" (2235) 7'-4" (2235)	7'-4" (2235) 7'-4" (2235) 7'-4" (2235)	9'-2" (2794) 9'-8" (2946) 10'-2 <sup>1</sup> ⁄4" (3105)	5'-6 <sup>3</sup> ⁄16" (1681) 5'-6 <sup>3</sup> ⁄16" (1681) 5'-6 <sup>3</sup> ⁄16" (1681)	7'-7 <sup>7</sup> / <sub>16</sub> " (2323) 8'-1 <sup>3</sup> / <sub>8</sub> " (2473) 8'-9 <sup>3</sup> / <sub>16</sub> " (2672)	4'-0" (1219) 4'-0" (1219) 4'-0" (1219)
(2438, 2743 or 3048 mm)	ping	щ	2000 (907) 2500 (1134)	SSP SSP-CO	7'-4" (2235) 8'-4" (2540)	7'-8" (2337) 8'-8" (2642)	6'-3¼" (1911) 6'-3¼" (1911)	5'-8" (1727) 6'-8" (2032)	4'-3" (1295) 4'-3" (1295)	3'-0" (914) 3'-6" (1067)
Entrance Height G	Opening	PASSENGER	3000 (1361)	SSP-CO	8'-6" (2591)	8'-8" (2642)	6'-11" (2108)	6'-8" (2032)	5'-0" (1524)	3'-6" (1067)
7, 8 or 9 ft.	Reverse	PAS	3500 (1588) 4000 (1814)	SSP-CO CO	8'-6" (2591) 9'-4" (2845)	8'-8" (2642) 9'-4" (2845)	7'-5¼" (2267) 7'-5¼" (2267)	6'-8" (2032) 7'-5 <sup>13</sup> ⁄16" (2281)	5'-6¾6" (1681) 5'-6¾6" (1681)	3'-6" (1067) 4'-0" (1219)
(2134, 2438 or 2743 mm)	<u>ک</u> ہ	/ICE	4000 (1814)	2SP	7'-4" (2235)	7'-4" (2235)	10'-1½" (3086)	5'-6¾(1681)	7'-7 <sup>7</sup> /16" (2323)	4'-0" (1219)
	Front	SERVICE	4500 (2041) 5000 (2268)	2SP 2SP	7'-4" (2235) 7'-4" (2235)	7'-4" (2235) 7'-4" (2235)	10'-7½" (3238) 11'-3¼" (3435)	5'-6¾16" (1681) 5'-6¾16" (1681)	8'-1¾" (2473) 8'-9¾6" (2672)	4'-0" (1219) 4'-0" (1219)


CONTROL SPAC	CE	J	K	L	CLEAR OVERH	iead Η Ai	ND PIT DEF	TH 📘			
CAPACITY LBS.	CONTROLLER	WIDTH	DEPTH	DOOR WIDTH			(.75 m/s)	200 FPM	(1.00 m/s)	350 FPM	(1.78 m/s)
(kg)	SPACE	(mm)	(mm)	(mm)	CAPACITY LBS. (kg)	Pit Depth (mm)	Clear Overhead	Pit Depth (mm)	Clear Overhead	Pit Depth (mm)	Clear Overhead
2000 to 5000	integral or	4'-0"	1'-8"	3'-6"			(mm)		(mm)		(mm)
(907 to 2268)	remote closet	(1219)	(508)	(1067)	2000 to 3500	5'-0"	13'-0"	5'-0"	13'-1"	5'-6"	13'-4"
2000 to 5000	adjacent room	5'-0"	dimension (B)	3'-0"	(907 to 1588)	(1524)	(3962)	(1524)	(3988)	(1676)	(4064)
(907 to 2268)	,	(1524)	. ,	(914)	4000 to 5000 (1814 to 2268)	5'-0" (1524)	13'-0" (3962)	-	-	-	-


#### **Section View**



Visit www.kone.us for the latest project-specific details, CAD drawings, CSI specifications, electrical data, reaction loads and building access requirements.







Adjacent or Remote Control Room (option 2)

#### Notes

- A hoist beam (by KONE) is required for installation (by others). Dimension H reflects clear under hoist beam.
- (2) If an EBD (Emergency Battery Device) is required please contact your KONE Sales Professional for further detail regarding dimensions H, and .
- (3) The published hoistway A dimensions represent the minimum clear inside requirements. Construction efficiencies can be realized by increasing these dimensions by up to 2" (51 mm).
- (4) For pit depths less than 5'-0" (1524 mm) please contact a KONE Sales Professional.
- (5) If occupied space exists below the hoistway, consult your KONE Sales Professional.
- (6) All dimensions are based on an 8'-0" (2438 mm) cab with a 7'-0" (2134 mm) door. Alternate car and door heights are available, but will affect dimension H.
- (7) Contact your local KONE Sales Representative regarding local code variations when utilizing the integrated, integral and remote closet options.
- (8) 150 fpm (.75 m/s) only available up to 85 ft. (25 m) of travel and 10 landings. 200 fpm (1.00 m/s) available up to 100 ft. (30.5 m) of travel and 12 landings.
- (9) 150 fpm (.75 m/s) is maximum speed available for capacities greater than 3500 lbs. (1588 kg).
- (10) 200 fpm (1.0 m/s) is maximum speed available for Integrated Control Solution.



**U.S. Operations Center** One KONE Court Moline, Illinois 61265 1-800-956-KONE (5663)

**Canadian Operations Centre** 6696 Financial Drive, Unit 2 Mississauga, Ontario L5N 7J6 1-905-858-8383

#### KONE Mexico, S.A. de C.V.

Av. Coyoacán 1622 Ed. 1 PB Col. Del Valle Sur México City, D.F. CP 03100 +52.55.1946.0100

For the latest product information and interactive design tools, visit www.kone.us

This publication is for general informational purposes only. KONE Inc. reserves the right to alter the product design and specifications without prior notice. Minor differences between printed and actual colors may exist.

KONE EcoDisc<sup>®</sup>, KONE EcoSpace<sup>™</sup>, KONE Polaris<sup>™</sup> and Dedicated to People Flow<sup>™</sup> are registered trademarks or trademarks of KONE Corporation. Copyright © 2015 KONE Inc.

"USGBC" and related logo is a trademark owned by the U.S. Green Building Council and is used by permission.

#### **U.S. Offices**

Alabama	
Birmingham	205-944-1032
Mobile	251-661-7522
Arizona	
Phoenix	623-434-3599
Tucson	520-624-3125
	320-024-3123
Arkansas	
Little Rock	501-758-1889
California	
Cypress	714-890-7080
Sacramento	916-372-1458
San Diego	858-578-5100
San Francisco	510-351-5141
San Francisco	510 551 5111
(Bay Area)	415-554-0580
Santa Barbara	805-349-1013
	005-547-1015
Colorado	
Denver	303-792-3423
Connecticut	
Hartford	860-257-9277
Delaware	856-251-1555
District of Columbi	a
Washington, DC	301-459-8660
5	501-457-0000
Florida	
Jacksonville	904-292-0225
Miami	954-437-4300
Naples	239-598-9310
Orlando	407-812-8033
Tampa	813-635-0330
Georgia	
Atlanta	770-427-3373
Hawaii	000 02 ( 0001
Honolulu	808-836-2231
Idaho	801-977-1144
Illinois	
Chicago	630-629-3100
Peoria	309-697-9011
Quad Cities	309-797-3232
Rockford	815-874-1502
Springfield	217-544-5461
Indiana	
	260 494 0596
Fort Wayne	260-484-9586 317-788-0061
Indianapolis	31/-/00-0001

<b>lowa</b> Des Moines Quad Cities	515-243-0109 309-797-3232
Kansas Wichita	316-942-1201
Kentucky Louisville	502-491-0565
Louisiana Baton Rouge New Orleans	225-291-5270 504-736-0776
Maine	781-828-6355
Maryland Baltimore	410-766-2100
Massachusetts Boston	781-828-6355
<mark>Michigan</mark> Detroit Grand Rapids	734-513-6944 616-534-3300
Minnesota Minneapolis	651-452-8062
<mark>Mississippi</mark> Jackson	601-939-7597
<b>Missouri</b> Kansas City St. Louis Springfield	816-531-2140 314-521-8800 417-862-1174
<mark>Montana</mark> Helena	406-449-1399
<mark>Nebraska</mark> Omaha	402-592-7381
<mark>Nevada</mark> Las Vegas	702-269-0919
New Hampshire	781-828-6355
<b>New Jersey</b> Warren	908-626-0220
New Mexico Albuquerque	505-888-0626
New York Albany New York City	518-464-0002 718-361-7200
North Carolina Charlotte	704-597-0430

Ohio Cincinnati Cleveland Columbus Oklahoma Oklahoma City Tulsa Oregon Portland Pennsylvania Harrisburg Philadelphia Pittsburgh **Rhode Island** South Carolina South Dakota Sioux Falls Tennessee Knoxville Memphis Nashville Texas Austin Dallas Houston San Antonio Utah Salt Lake City Vermont Virginia Richmond Washington Seattle West Virginia Charleston Morgantown

North Dakota

513-755-6195 440-546-1100 614-866-1751 405-682-5651 918-258-0582 503-652-1011 717-653-7177 856-488-8830 412-279-1561 781-828-6355 704-507-0430 605-336-1578 865-938-3444 901-758-8320 615-360-7013 512-443-0967 469-549-0581 281-442-6619 210-491-0485 801-977-1144 781-828-6355 804-328-1032 425-861-9696 614-866-1751 412-279-1561 262-373-0460 303-792-3423

651-452-8062

#### **Canada Offices**

Alberta Calgary	403-275-5650	Manitoba Winnipeg	2
Edmonton	780-452-9227	Nova Scotia	
British Columbia		Bedford	9
Vancouver Victoria Kelowna	604-777-5663 250-384-0613 778-436-8150	Ontario Hamilton Kingston Ottawa	9

Manitoba Winnipeg	204-895-2942
Nova Scotia Bedford	902-450-1102
Ontario	
Hamilton	905-648-3188
Kingston	613-531-6262
Ottawa	613-225-8222
Toronto	905-948-2230

FSC



Sherbrooke

Wisconsin

Milwaukee

Wyoming

514-284-5663 418-877-1494 819-821-2182



